

FR-S SERIES

Make operations simple
with the setting dial!

**400V Class
Now Available!**



Mitsubishi Electric Corporation Nagoya Works is a factory certified for ISO14001 (standards for environmental management systems) and ISO9001(standards for quality assurance management systems)



1

Quick Setting using Setting Dial

- The frequency and parameters etc. can be set with a few simple steps.
- Easily set values: turn quickly to greatly change the value, and turn slowly to finely adjust the value.
- Accurate settings can be made with the new notch-type "clicking" feel.



The setting dial is your new tool for operations!!
See how easy it is to make simple operation settings.

2


Simple Operation

- As the default, the parameters that can be set have been grouped into the minimum required twelve parameters. Thus, parameters can be managed easily.
- The modes can be changed between the PU and external operation modes just by pressing the PU/EXT (operation mode changeover) key. The current operation mode can be confirmed with the status display LED.
- The set frequency and the output current value can be monitored just by using the setting dial (set frequency monitor) or SET key (output current value monitor). (When in the monitor display state.)



Example of PU operation mode

3 Automatic Torque Boost Control



- By incorporating Mitsubishi's original and newly developed "automatic torque boost control", a maximum 150% torque at 6Hz is possible.
- The need for torque boost setting can be eliminated and the current during no load can be controlled. Example speed-torque characteristics using newly developed automatic torque boost control is shown on the left.
(For SF-JR 4P 0.75kW motor)

4 Compact Design

- The foot print is the same as the Mitsubishi FREQROL-E520.
- (400V class installation area has been unified to 108mm(128m.)
- The height dimensions for all capacities have been unified to 128mm, making panel layout easier.



5 Environment Awareness

- The popular Soft-PWM control is incorporated as standard. An increase in noise can be reduced, and noise can be suppressed to a minimum.
- Reactor connection to aid harmonic suppression. The compact and lightweight DC reactor (FR-BEL) can be connected. Connect an AC reactor (FR-BAL) when using the single-phase 100V class.

6 Easy Maintenance

- The cooling fan can be replaced easily due to a simple cassette design. By setting the fan "ON-OFF control", operation with an extended life can be realized. (The ON-OFF control is set as the default.)
- Wiring space is secured and the wiring work efficiency is enhanced by incorporating an expanded front cover and comb-type wiring cover.



7 Global specification

- Compatible with UL, cUL and EN (CE Mark).



8 Other Handy Functions

- Terminal function (multi-speed 15 of speeds, error reset, output stop, etc.) can be selected
- In-rush current suppression circuit is standard for all capacities
- PID control
- 4 to 20mA input
- Sink/Source logic is selectable

CONTENTS

Control panel	2
Model Configuration	3
General Specifications	4
Common Specifications	4
External Dimension Drawings	5
Terminal connection diagram	5
Explanation of Terminals	5
List of Parameters	6
Explanation of Parameters	7
Alarm Displays	8
Selecting Peripheral Devices	8
List of Options	8
Precautions	9


Control panel

RUN display
Shows the operation state.

3-digit LED monitor
Shows the parameter number and setting value.

PU display/EXT display
Shows operation mode.

Setting dial
Sets the frequency, and changes the parameter setting.



PU/EXT key:
Changes the operation mode.
PU=Control panel operation mode
EXT=External operation mode

RUN key:Forward run
(Can be changed to reverse run with parameter settings.)

STOP/RESET key:
Stop/reset (at alarm)

MODE key:
Changes the setting mode.


SET key:
Sets the frequency setting and parameter setting.

Basic operations (At default setting)

Monitor and frequency setting




(Screen at power ON)
This screen appears.



Press the MODE key.


[Example] Operating with the control panel

Press the PU/EXT key to display PU.



Return to the monitor and frequency setting.


Parameter setting




Press the MODE key.

[Example] Changing the parameter setting

Press the PU/EXT key to display PU.



Alarm history



Press the MODE key.

Note: If the parameters are set in the external operation mode (When only EXT is lit), Er2 (error) may appear depending on the parameter.

Type

FR — S520 — 0.1K —

Symbol	Voltage
1	100V class
2	200V class
4	400V class

Symbol	No. of power supply phases, etc.
None	3-phase input
S	Single-phase input
W	Single-phase input (double voltage output)

Symbol	Inverter capacity
0.1K	Indicates capacity (kW)
1	
3.7K	


Symbol	Structure, communication function, etc.
None	Enclosed type
R	RS-485 function provided
C	Totally enclosed structure (IP40)

Model Configuration

Power specifications	Inverter type (The inverter capacity is shown in the box)	Inverter capacity						Remarks
		0.1K	0.2K	0.4K	0.75K	1.5K	2.2K	
3-phase 200V	FR-S520-□K	●	●	●	●	●	●	
	FR-S520-□K-R	●	●	●	●	●	●	
	FR-S520-□K-C	●	●	●	●	●	●	
3-phase 400V	FR-S540-□K	—	—	●	●	●	●	
	FR-S540-□K-R	—	—	●	●	●	●	
Single-phase 200V (Note)	FR-S520S-□K	●	●	●	●	●	—	
	FR-S520S-□K-R	●	●	●	●	●	—	
Single-phase 100V (Note)	FR-S510W-□K	●	●	●	●	—	—	
	FR-S510W-□K-R	●	●	●	●	—	—	

(Note) The output is 3-phase 200V.


● : Available model, — : No correspondence



Turn the setting dial.



The desired frequency setting will appear.




Press the SET key within 5s after turning the dial.

Writing of the frequency setting is completed!


F and frequency flicker

Starts when **RUN** is pressed.


Stops when **STOP RESET** is pressed.



Turn the setting dial.



The parameter No. will appear.




Press the SET key after turning the dial. The currently set number will be read out.


Setting of the parameters is completed!

Parameter No. and changed value flicker


Turn the setting dial, and set the number of the next parameter to be changed.



Turn the setting dial.



The desired setting value will appear.



Press the SET key after turning the dial.

After reading and changing the setting:

- Press the MODE key once to return to the Alarm History screen.
- Press the MODE key twice to return to the Monitor and Frequency Setting screen.

General Specifications

Specifications	3-phase 200V							3-phase 400V					Single-phase 200V					Single-phase 100V				
	FR-S520-□□							FR-S540-□□					FR-S520S-□□					FR-S510W-□□				
Type	0.1K	0.2K	0.4K	0.75K	1.5K	2.2K	3.7K	0.4K	0.75K	1.5K	2.2K	3.7K	0.1K	0.2K	0.4K	0.75K	1.5K	0.1K	0.2K	0.4K	0.75K	
Applicable motor capacity (kW) (Note 1)	0.1	0.2	0.4	0.75	1.5	2.2	3.7	0.4	0.75	1.5	2.2	3.7	0.1	0.2	0.4	0.75	1.5	0.1	0.2	0.4	0.75	
Output	Rated capacity (kVA)(Note 2)	0.3	0.5	1.0	1.6	2.8	4.0	6.6	0.9	1.6	2.7	3.7	5.9	0.3	0.5	1.0	1.6	0.3	0.5	1.0	1.6	
	Rated current (A)	0.8	1.4	2.5	4.1	7.0	10	16.5	1.1	2.1	3.5	4.8	7.7	0.8	1.4	2.5	4.1	7.0	0.8	1.4	2.5	4.1
	Overload current rating (Note 3)	150% for 60 s, 200% for 0.5 s (Inverse time characteristics)																				
	Voltage (Note 4)(Note 6)	3-phase 200 to 240V, 50/60 Hz							3-phase 380V to 480V, 50/60 Hz					3-phase 200 to 240V, 50/60 Hz					3-phase 200V to 230V, 50/60Hz			
Power supply	Rated input AC voltage/frequency	3-phase 200 to 240V, 50/60 Hz							3-phase 380V to 480V, 50/60 Hz					Single-phase 200 to 240V, 50/60Hz					Single-phase 100V to 115V, 50/60Hz			
	Tolerable AC voltage fluctuation	170 to 264V, 50/60Hz							325V to 528V, 50/60Hz					170 to 264V, 50/60Hz					90V to 132V, 50/60Hz			
	Tolerable frequency fluctuation	Within ±5%																				
	Power facility capacity(kVA)(Note 5)	0.4	0.7	1.2	2.1	4.0	5.5	9	1.5	2.5	4.5	5.5	9.5	0.5	0.9	1.5	2.5	4.4	0.5	0.9	1.5	2.5
Protective structure (JEM 1030)	Enclosed type (IP20) (Fully enclosed structure series is IP40)																					
Cooling method	Self-cooling							Forced cooling					Self-cooling					Forced cooling				
Approximately weight (kg)	0.5	0.5	0.8	0.9	1.5	1.5	2.1	1.5	1.5	1.5	1.6	1.7	0.5	0.6	0.8	1.0	1.5	0.6	0.7	0.9	1.6	

- (Notes) 1. The applicable motor indicates the maximum applicable capacity when using a Mitsubishi standard 4-pole motor.
2. The rated output capacity is 230V for the 3-phase 200V output voltage, and 440V for the 3-phase 400V output voltage.
3. The overload current rating percentage indicates the percentage in respect to the inverter's rated output current. When used repeatedly, it is necessary to wait for the inverter motor to return to a temperature less than the temperature for the 100% load.
4. The maximum output voltage will not exceed the power supply voltage for the 3-phase 200V/400V power input specification product and the single-phase 200V power input specification product. The single-phase 100V power input specification product cannot output more than twice the power voltage.
5. The power capacity will change according to the power side impedance (including the input reactor or wire) values.
6. For the single-phase 100V power input specification product, when a load is applied on the motor, the output voltage will drop by approx. 10 to 15%. However, when using a general-purpose motor, the load must be reduced before use.


Common Specifications

Control specifications	Control method	Select from V/F control (Soft-PWM control/high carrier frequency PWM control selective) and automatic torque boost control	
	Output frequency range	0.5 to 120Hz (starting frequency can be varied between 0 and 60Hz)	
	Frequency setting resolution	5VDC input: 1/500 of maximum setting frequency, 10VDC, DC4 to 20mA input: 1/1000 of maximum setting frequency Digital input: 0.1Hz (less than 100Hz), 1Hz (100Hz or more)	
	Frequency precision	Analog input: Within ±1% of maximum output frequency (25°C ± 10°C) Digital input: Within ±0.5% of set output frequency (when setting dial is used)	
	Starting torque	150% (at 6Hz) during automatic torque boost control	
	Acceleration/deceleration time setting	0.01 to 999 s (acceleration/deceleration can be set individually), linear or S-pattern acceleration/deceleration mode can be selected	
	Braking torque	Regenerative (Note 1)	0.1K, 0.2K, ·· 150%, 0.4K, 0.75K, ·· 100%, 1.5K, ·· 50%, 2.2K, 3.7K ·· 20%
		DC braking	Operation frequency (0 to 120Hz), operation time (0 to 10 seconds), operation voltage (0 to 15%)
	Input signals	Frequency setting signal (0 to 5 (10)VDC), 4 to 20mA, digital setting with setting dial, start signal, error reset (RES), multi-speed selection (RL, RM, RH, REX), 2nd function selection (RT), output stop (MRS), current input selection (AU), external thermal input (OH), start self-hold selection (STOP), JOG mode selection (JOG), PID action selection (X14), PU operation/external operation changeover (X16)	
	Operation functions	Upper/lower limit frequency setting, frequency jump operation, external thermal input selection, restart after instantaneous power failure, forward/reverse run prevention, slip compensation, operation mode selection, PID control, computer link operation (RS-485) (Note 5)	
Output signals	Operation functions	One type of open collector output can be selected from inverter running (RUN), frequency reached (SU), frequency detection (FU), overload warning (OL), zero current detection (Y13), output current detection (Y12), PID upper limit (FUP), PID lower limit (FDN), PID forward/reverse run (RL), READY (RY), minor failure (LF), and error (A, B, C). One type can be selected for the contact output (1 contact, 230VAC 0.3A, 30VDC 0.3A).	
	For meter	One type can be selected from output frequency or motor current. Pulse train output (1440 pulse/s 1mA full scale).	
Environment	Protection and warning functions	Overcurrent cutoff (during acceleration, deceleration, and constant speed), regenerative overvoltage cutoff (during acceleration, deceleration, and constant speed), overload cutoff (electronic thermal relay), fan overheating, fan trouble (Note 4), stall prevention, output side ground fault protection at starting (Note 7), external thermal input (Note 6), PU dislocation (Note 5), No. of retries exceeded, communication error (Note 5), CPU error, undervoltage (Note 2)	
	Ambient temperature and humidity	-10°C to +50°C (non freezing), (-10°C to +40°C for fully enclosed structure specifications), 90%RH or less (non condensing)	
	Storage temperature (Note 3)	-10°C to +65°C	
	Altitude and vibration	Indoors with no corrosive gases, flammable gases, oil mist or dust 1000m or less above sea level, 5.9m/s ² or less (JIS C 0040 compliant)	


- (Notes) 1. The indicated braking torque is the short-term average torque (which changes with motor loss) when the motor alone is decelerated from 60Hz. It is not the continuous regenerative torque. Deceleration from frequencies exceeding the base frequency will have a lower average deceleration torque value.
2. If an undervoltage occurs, an error will not be output, but the output will be cutoff. Operation can be resumed after restoring the power, but depending on the operation state (size of load, etc.), the overcurrent protection or regenerative overvoltage protection may function when the power is restored.
3. This is the temperature to which units can be exposed for a short time, such as during transportation.
4. This corresponds only to the products with built-in cooling fan.
5. This applies only to the type with RS-485 function.
6. This functions only when the external thermal input (OH) is selected with Pr. 60 to Pr. 63 (input terminal function selection).
7. This functions only when Pr. 40 (start-time ground fault detection selection) is set to 1.

External Dimension Drawings (Unit: mm)


- FR-S520-0.1K, 0.2K, 0.4K, 0.75K
- FR-S520S-0.1K, 0.2K, 0.4K, 0.75K
- FR-S510W-0.1K, 0.2K, 0.4K



- FR-S520-1.5K, 2.2K, 3.7K
- FR-S540-0.4K, 0.75 K, 1.5K, 2.2K, 3.7K
- FR-S520S-1.5K
- FR-S510W-0.75K



Terminal connection diagram



- (Notes) 1. This is not required when calibrating with the setting dial. Use this when calibrating the frequency meter manually because the frequency meter is at a remote location etc. Note that when the scale calibration resistor is connected, the needle on the frequency meter may not adjust to the full scale. In this case, calibrate with the setting dial.
 2. If the setting unit is used frequently, use the 2W1kΩ potentiometer.
 3. This is provided only with the type having the RS-485 function.
 4. This is a connection example for when the control circuit logic is sink (default setting).
 5. When using the current input for the frequency setting signal, set one of the parameters between Pr. 60 and Pr. 63 (terminal function selection) to 4, and assign one of the terminals RH, RM, RL or STR to AU (current input selection).
 6. This cannot be mounted on the single-phase 100V power input specification product.
 7. The single-phase 100V power input specification product does not have terminals.
 8. The RL, RM, RH, RT, AU, STOP, MRS, OH, REX, JOG, RES, X14 and X16 signals can be selected with the input terminal function selection (Pr. 60 to 63).
 9. The RUN, SU, OL, FU, RY, Y12, Y13, FDN, FUP, RL, LF, and ABC signals can be selected with the output terminal function selection (Pr. 64, 65).

Explanation of Terminals

Terminal symbol	Terminal name	Detailed explanation	
Main circuit	R, S, T	Power supply input	Connect to the commercial power supply.
	U, V, W	Inverter output	Connect to the 3-phase squirrel cage motor.
	N	DC voltage common	This is the DC voltage common terminal. It is not insulated from the power supply and inverter output.
	P, P1	Power factor improvement DC reactor connection	Remove the short-circuit bar between terminals P and P1 and connect the optional power factor improvement DC reactor (FR-BEL). (This cannot be connected with the FR-S510W-□□K-(R).)
	⊕	Grounding	This is for grounding the inverter chassis. Always ground the inverter.
Control circuit (input signal)	STF	Forward run start	This functions as the forward run command when the STF signal is ON, and the stop command when the signal is OFF.
	STR	Reverse run start	This functions as the reverse run command when the STR signal is ON, and the stop command when the signal is OFF.
	RH, RM, RL	Multi-speed selection	The multi-speed type can be selected by combining the terminal RH, RM and RL signal short circuits.
	SD	Contact input common (sink)	This is the common terminal for the contact input (terminals STF, STR, RH, RM, RL) and meter connection (terminal FM). Terminal 5 and terminal SE are insulated.
	PC	External transistor common 24VDC power supply contact input common (source)	When connecting a transistor output (open collector output) such as a programmable controller (PLC), malfunctioning caused by the supplied current can be prevented by connecting the external power supply common for the transistor output to this terminal. This can be used as the 24VDC 0.1A power supply between terminals PC and SD. When the source logic is selected, this will be the common terminal for the contact input signal.
	10	Frequency setting power supply	5VDC. Tolerable load current 10mA.
	2	Frequency setting (voltage signal)	When 0 to 5VDC (0 to 10V) is input, the maximum output frequency will be reached at 5V (10V), and the input/output will be proportional. Change between 5V and 10V with Pr. 73. The input resistance is 10kΩ, and the maximum tolerable input voltage is 20V.
	5	Frequency setting input common	This is the common terminal for the frequency setting signal (terminal 2, 4). This is insulated from terminal SD and terminal SE. Do not ground this common.
	4	Frequency setting (current signal)	Input 4 to 20mA DC. The default setting is adjusted to 0Hz at 4mA and 60Hz at 20mA. The maximum tolerable input current is 30mA, and the input resistance is approximately 250Ω.
	Control circuit (output signal)	A, B, C	Error output (relay output)
RUN		Inverter running	The L level is output when the inverter output frequency is higher than the starting frequency (0.5Hz default can be changed). The H level is output when stopped or during DC braking (Note 1). The tolerable load is 24VDC 0.1A.
SE		Open collector common	This is the common terminal for the terminal RUN. This is insulated from terminal 5 and terminal SD.
FM		Display connection	The inverter is set so that the terminals FM to SD will output approximately 1mA at 60Hz (default value). The output frequency is proportional. The output voltage is a pulse waveform, so a digital display can be connected. Pulse specifications: 1440 pulses/s at 60Hz.
Communication	—	RS-485 connector (Note 2)	Communication with RS-485 is possible. <ul style="list-style-type: none"> Standard compliance: EIA Standards RS-485 Transmission format: Multidrop link method Communication speed: Max. 19200 baud, * Total length: 500m The parameter unit FR-PU04 can be connected using the parameter unit connection cable FR-CB201 to 205.

- (Notes) 1. The L level refers to when the open collector output transistor is ON (continuity state). The H level refers to when the transistor is OFF (non-continuity state).
 2. This is provided only with the type having the RS-485 function.

List of Parameters

Basic functions <default state>

Function	Parameter	Name	Setting range	Minimum setting unit	Default setting
Basic functions	0	Torque boost	0~15%	0.1%	6%/5%/4% (Note 4)
	1	Maximum frequency	0~120Hz	0.1Hz	60Hz
	2	Minimum frequency	0~120Hz	0.1Hz	0Hz
	3	Base frequency	0~120Hz	0.1Hz	60Hz
	4	Multi-speed setting (high speed)	0~120Hz	0.1Hz	60Hz
	5	Multi-speed setting (medium speed)	0~120Hz	0.1Hz	30Hz
	6	Multi-speed setting (low speed)	0~120Hz	0.1Hz	10Hz
	7	Acceleration time	0~999 s	0.1 s	5 s
	8	Deceleration time	0~999 s	0.1 s	5 s
	9	Electronic thermal O/L relay	0~50A	0.1A	Rated output current (Note 3)
	30	Extended function display selection	0, 1	1	0
	79	Operation mode selection	0~4, 7, 8	1	0

- (Notes) 1. The shaded parameters can be changed even during operation.
 2. This parameter is provided only with the type having the RS-485 communication function.
 3. This will be 85% of the rated output current for 0.75K or less.
 4. This will be 5% for FR-S540-1.5K and 2.2K, and 4% for FR-S540-3.7K.

By setting parameter 30 to 1, the following extended function parameters can be set.

Extended functions


Function	Parameter	Name	Function	Parameter	Name	Function	Parameter	Name	
Standard operation functions	10	DC injection brake operation frequency	Current detection	50	Zero current detection level	PID control	88	PID operation selection	
	11	DC injection brake operation time		51	Zero current detection time		89	PID proportional band	
	12	DC injection brake voltage		Display functions	52		Control panel display data selection	90	PID integral time
	13	Starting frequency			53		Frequency setting operation selection	91	PID upper limit
	14	Load pattern selection			54		FM terminal function selection	92	PID lower limit
	15	JOG frequency			55		Frequency monitor reference	93	PID control set point during PU operation
	16	JOG acceleration/deceleration time	56	Current monitor reference	94	PID differential time			
	17	RUN key rotation direction selection	Restart	57	Restart coasting time	Slip compensation	95	Motor rated slip	
	19	Base frequency voltage		58	Restart cushion time		96	Slip compensation time constant	
	20	Acceleration/deceleration reference frequency	Remote setting	59	Remote setting function selection / Frequency setting storage function selection		97	Constant output area slip compensation selection	
	21	Stall prevention function selection				Terminal function selection	60	RL terminal function selection	Automatic torque boost
	22	Stall prevention operation level	61	RM terminal function selection	99		Motor primary resistance		
	23	Stall prevention operation level compensation factor at double speed	62	RH terminal function selection	Communication/PU function (Note 2)		n 1	Communication station number	
	24	Multi-speed setting (speed 4)	63	STR terminal function selection			n 2	Communication speed	
	25	Multi-speed setting (speed 5)	64	RUN terminal function selection			n 3	Stop bit length	
	26	Multi-speed setting (speed 6)	65	A, B, C terminal function selection			n 4	Parity check presence/absence	
	27	Multi-speed setting (speed 7)	Operation selection functions	66			Retry selection	n 5	Number of communication retries
	28	Stall prevention operation reduction starting frequency		67			Number of retries at alarm occurrence	n 6	Communication check time interval
	29	Acceleration/deceleration pattern		68		Retry waiting time	n 7	Wait time setting	
	31	Frequency jump 1A		69		Retry count display erase	n 8	Operation command write	
	32	Frequency jump 1B		70	Soft-PWM setting	n 9	Speed command write		
	33	Frequency jump 2A		71	Applicable motor	n 10	Link start mode selection		
	34	Frequency jump 2B		72	PWM frequency selection	n 11	CR/LF selection		
	35	Frequency jump 3A		73	0 to 5V/0 to 10V selection	n 12	E ² PROM write validity selection		
	36	Frequency jump 3B		74	Input filter time constant	n 13	PU display language		
	37	Speed display		75	Reset selection/ PU stop selection	n 14	PU buzzer sound control		
	38	Frequency setting voltage gain frequency	76	Cooling fan operation selection	n 15	PU contrast adjustment			
	39	Frequency setting current gain frequency	77	Parameter write disable selection	n 16	PU main display screen data selection			
	40	Start-time ground fault detection selection	78	Reverse rotation prevention selection	n 17	PU dislocation detection/PU setting lock			
	Output terminal functions	41	Up-to-frequency sensitivity	Multi-speed operation functions	80	Multi-speed setting (speed 8)	Calibration functions	c 1	FM terminal calibration
		42	Output frequency detection		81	Multi-speed setting (speed 9)		c 2	Frequency setting voltage bias frequency
		43	Output frequency detection at reverse rotation		82	Multi-speed setting (speed 10)		c 3	Frequency setting voltage bias
		44	2nd acceleration/deceleration time		83	Multi-speed setting (speed 11)		c 4	Frequency setting voltage gain
	45	2nd deceleration time	84		Multi-speed setting (speed 12)	c 5		Frequency setting current bias frequency	
	46	2nd torque boost	85		Multi-speed setting (speed 13)	c 6		Frequency setting current bias	
	47	2nd V/F (base frequency)	86		Multi-speed setting (speed 14)	c 7		Frequency setting current gain	
	48	Output current detection level	87		Multi-speed setting (speed 15)	c 8		Parameter for manufacturer setting. Do not set.	
	Current detection	49	Output current detection signal delay time	Auxiliary functions	CLr	Parameter clear	ECL	Alarm history clear	

Explanation of Parameters

"Pr." is the abbreviation of parameter.


Pr.0 Torque boost

- The motor torque in the low frequency area can be adjusted according to the load.



Pr.1 Pr.2 Maximum/minimum frequency

- The upper limit and lower limit of the output frequency is clamped.



Pr.3 Base frequency


- Set the base frequency (reference frequency for motor rated torque) between 0 and 120Hz according to the motor.

Pr.4 Pr.5 Pr.6 Multi-speed setting

- Various speeds (RH, RM, RL) can be selected just by changing the contact signal from an external source.
- Each speed (frequency) can be set between 0 and 120Hz while the inverter is running.

Pr.7 Pr.8 Acceleration/deceleration time

- For the acceleration time, set the time to reach the acceleration/deceleration reference frequency Pr. 20 (default value: 60Hz) from 0Hz, and for the deceleration time, set the time to reach 0Hz from Pr. 20 (default value: 60Hz).



Pr.9 Electronic thermal O/L relay

- The setting value to protect the motor from overheating can be set as a current value. Normally, the motor rated current is set for 50Hz.
- When 0A is set, the motor protective function will not activate. (The inverter output transistor's protective function will activate.)
- When connecting multiple motors, set an external thermal relay for each motor.

Pr.30 Extended function display selection

- Set this to display and set the extended function parameters.

Setting value	Details
0	Display only basic functions
1	Display all parameters

Pr.79 Operation mode selection

- The inverter operation modes include operation with external signal and operation with the PU (setting dial, touch keys). The mode can be fixed to one mode, or two modes can be used together.

※Refer to the Instruction Manual for details.

Setting value	Details	
0	Operation is possible by changing between PU (setting dial, touch key) operation or external operation.	
1	Operation is possible only with PU (setting dial, touch key) operation.	
2	Only external operation is possible.	
3	Operation frequency	Starting signal
	Setting with setting dial · Multi-speed selection · 4 to 20mAADC input	External terminal (STF/STR)
4	Operation frequency	Starting signal
	External terminal signal (Multi-speed, 0 to 5VDC, etc.)	RUN key
7	PU operation interlock	
8	Operation mode external signal changeover Select operation mode by turning PU operation/external operation mode changeover (X16) signal ON and OFF.	

Alarm Displays

Protective function name	Main LED display	Fault class (Note 3)	Protective function name	Main LED display	Fault class (Note 3)	Protective function name	Main LED display	Fault class (Note 3)		
Overcurrent cutoff	Accelerating	OC1	Major fault	Fan trouble	F _n	Minor fault	Communication error (Note 2)	OPF	Major fault	
	Constant speed	OC2	Major fault	Stall prevention	Overload	OL _r	Major fault	CPU error	CPU	Major fault
	Decelerating	OC3	Major fault		Overcurrent speed loss	OL	—	Undervoltage (Note 4)	UV	—
Regenerative overvoltage cutoff	Accelerating	OU1	Major fault		Overvoltage speed loss	oL	—		Parameter setting error	Write disable error
Regenerative overvoltage cutoff	Constant speed	OU2	Major fault	External thermal relay (Note 1)	OH _r	Major fault	Write-while running error/ mode designation error	Er2		—
	Decelerating	OU3	Major fault	PU disconnected (Note 2)	PUE	Major fault	Calibration error	Er3		—
	Overload cutoff (electronic thermal overcurrent protection)	Transistor	FHF	Major fault	Output side ground fault protection (Note 5)	GF	Major fault			
Motor		FHN	Major fault	Retry count	rEF	Major fault				
Fin overheat	FIN	Major fault	Parameter memory element error	PE	Major fault					

- (Notes) 1. This functions only when the external thermal relay input (OH) is selected with Pr. 60 to Pr. 63 (input terminal function selection).
 2. This applies only when the RS-485 communication function is provided.
 3. Major fault : The protective function activates, inverter output is shut off, and an error output is provided.
 Minor fault : Output is not shut off even when the protective function activates. It is possible to output minor fault signals by making parameter settings.
 4. An error is not output when an undervoltage occurs, but the inverter output is cut off. The operation can be resumed after the power is recovered.
 5. This activates only when Pr. 40 (ground fault detection at starting selection) is set to 1.
 6. Refer to the instruction manual for details on PS and Err displays.

Selecting Peripheral Devices

Power voltage	Motor output (kW)	Applicable inverter type	No-fuse breaker (NFB) Earth leakage breaker (NV)	Magnetic contactor (MC)	Wire (mm ²) (Note 1)		
					R,S,T	U,V,W	
3-phase 200V	0.1	FR-S520-0.1K(-R,C)	30AF 5A	S-N10	2	2	2
	0.2	FR-S520-0.2K(-R,C)	30AF 5A	S-N10	2	2	2
	0.4	FR-S520-0.4K(-R,C)	30AF 5A	S-N10	2	2	2
	0.75	FR-S520-0.75K(-R,C)	30AF 10A	S-N10	2	2	2
	1.5	FR-S520-1.5K(-R,C)	30AF 15A	S-N10	2	2	2
	2.2	FR-S520-2.2K(-R,C)	30AF 20A	S-N11,S-N12	2	2	2
3-phase 400V	3.7	FR-S520-3.7K(-R,C)	30AF 30A	S-N20	3.5	3.5	3.5
	0.4	FR-S540-0.4K(-R)	30AF 5A	S-N10	2	2	2
	0.75	FR-S540-0.75K(-R)	30AF 5A	S-N10	2	2	2
	1.5	FR-S540-1.5K(-R)	30AF 10A	S-N10	2	2	2
	2.2	FR-S540-2.2K(-R)	30AF 15A	S-N20	2	2	2
	3.7	FR-S540-3.7K(-R)	30AF 20A	S-N20	2	2	2

(Note) 1. The wire size is for a wiring length of 20m.

List of Options

Name	Type	Application and specifications, etc.		Applicable inverter
Parameter unit (8 languages)	FR-PU04	Interactive parameter unit with LCD display	Can be used only with FR-S5□□-□K-R type with RS-485 communication function	Type with RS-485 communication function
Cable for connecting parameter unit	FR-CB201(1m) FR-CB203(3m) FR-CB205(5m)	Cable for connecting parameter unit and inverter		
Power factor improvement AC reactor	FR-BAL(H)□□(Note 2)(Note 8)	For power factor improvement (power factor approx. 90%)	Connect to input side	Compatible with 0.1K to 3.7K capacities
Power factor improvement DC reactor	FR-BEL(H)□□(Note 2)(Note 6)(Note 8)	For power factor improvement (power factor approx. 95%)		
Radio noise filter	FR-BIF(H)(Note 8)	Reduces radio noise	Connect to input side	Common for all models
Line noise filter	FR-BSF01	Reduces line noise		
Surge voltage suppression filter	FR-ASF-H□□(Note 2)	For micro-surge voltage suppression		Compatible with FR-S540-0.4K to 3.7K capacities
BU type brake unit	BU(H)□□(Note 2)(Note 8)	Greatly increases regenerative braking performance		FR-S520-0.4K to 3.7K
Discharging resistor	GZG GRZG type	Discharging resistor for BU type brake unit		FR-S540-2.2K to 3.7K
High power factor converter	FR-HC-(H)7.5K(Note 8)	For suppressing higher harmonics		FR-S520-0.1K to 3.7K(Note 4) FR-S540-0.4K to 3.7K(Note 4)
Power regeneration common converter	FR-CV□□(AT)(Note 2)(Note 9)	Common converter type power regeneration brake unit		(Compatible with FR-S520-0.1K to 3.7K capacities)
Dedicated standalone reactor	FR-CVL-□□(Note 2)	Reactor for power regeneration common converter		Compatible with FR-S520-0.1K to 3.7K capacities
EMC command compatible noise filter (EU compatible)	SF-□□(Note 3) FR-S5NFS□-□□(Note 2) FR-ESNF-H□□(Note 2)	EMC Instruction (EN50081-2) compatible noise filter * Measures must be taken to prevent malfunction of peripheral devices (earth leakage breaker), etc., and electric shocks caused by leakage currents.		Compatible with FR-S520-0.1K to 3.7K (Note 5), FR-S520S-0.1K to 1.5K, FR-S510W-0.1K to 0.75K (Note 7) capacities FR-S540-0.4K to 3.7K
EMC filter installation attachment	FR-E5T	Attachment for installing EMC instruction compatible noise filter (SF1309) onto inverter		FR-S520-2.2K/3.7K
DIN rail installation attachment	FR-UDA01 FR-UDA02 FR-UDA03	DIN rail installation		Compatible with capacities
FF series controllers and setters (Note 1)	Operation box with frequency meter	FR-AX	For independent operation with frequency meter, frequency setting unit and start switch	Common for all models
	Sequential setting operation box	FR-AL	For sequential operation (1VA) with external signals (0 to 5VDC, 0 to 10VDC)	
	3-speed setting operation box	FR-AT	For operation changing between high, medium and low speed (1.5VA)	
	Remote operation box	FR-FK	For remote operation; operation from several places is possible (5VA)	
	Ratio setting box	FR-FH	For ratio operation; ratios for up to five inverters can be set.	
	PG follower	FR-FP	For follow-up operation using the signal of a pilot generator (PG). (2VA)	
	Master controller	FR-FG	Main speed setting unit for parallel operation of several inverters (up to 35 units). (5V)	
	Inclined signal box	FR-FC	For soft starting/stopping; parallel operation acceleration/deceleration is possible (3VA)	
	Deviation detector	FR-FD	For synchronous operation. Used with deviation sensor and synchro. (5VA)	
	Pre-amplifier box	FR-FA	Can be used as A/V converter or operation amplifier (3VA)	
	Pilot generator	QVAH-10	70/35VAC 500Hz for tracking operation (at 2500r/min)	
Deviation sensor	YVGC-500W-NS	For synchronous operation (mechanical deviation detection). Output 90VAC/90°		

- (Notes) 1. Rated power consumption for the FR Series operation and setting box power supply specifications are 200VAC 50Hz, 200/220V 60Hz, 115VAC 60Hz.
 2. The values given in boxes indicate the capacity.
 3. □□ indicates a value.
 4. One 3.7K inverter must be connected. (When using without the 3.7K inverter connected, use as a common converter or regenerative converter is possible, but the power higher harmonic suppression effect will drop.)
 5. The EMC filter installation attachment (FR-E5T) must be used when installing SF filter on the FR-S520-2.2K/3.7K.
 6. This cannot be mounted on the single-phase 100V power input specification product.
 7. A 0.75K filter capacity is used for the 0.4K or less inverter capacity, and a 1.5K filter capacity is used for the 0.75K inverter capacity.
 8. The 3-phase 400V input specification product is indicated with an "H" in the type.
 9. -AT indicates the type installed in the panel. If -AT is not added, this is an external cooling fin type. Note that either method can be used for the 37K and 55K types by changing the position of the installation legs, so -AT is not added.

Precautions

⚠ For Maximum Safety

- Always read the instruction manual before use to use the equipment properly and safely.
- This product is not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as equipment or systems used in passenger transportation, medical, aerospace, nuclear energy, electric power, or submarine relay applications, please contact your nearest Mitsubishi sales department.
- Although this product was manufactured under strict quality control conditions, it is strongly advised to install safety devices to forestall serious accidents when used in facilities where a breakdown of the product is likely to cause a serious accident.
- Please do not use for loads other than 3-phase induction motors.


Cautions for Use

■ Operation

- When a magnetic contactor (MC) is installed on the primary side, do not start and stop operation frequently with this MC. Failure to observe this could lead to inverter faults.
- When a fault occurs in the inverter, the protective function will activate and the output will stop, but the motor will not stop immediately. Thus, if the machine or facility requires emergency stop means, install mechanical stopping and holding mechanism.

■ Power supply

- If the unit is installed directly below a large-capacity power supply transformer (500kVA or more, with wiring length of 10m or less), or where the phase advance capacitor switches, an excessive peak current may flow to the power input circuit causing damage to the inverter. In this case, be sure to install the optional FR-BEL or FR-BAL power factor improvement reactor.
- If surge voltage is generated in the power system, this surge energy could flow into the inverter and cause the inverter to stop with the OV1, OV2 or OV3 alarm displayed. In this case, install the optional power factor improvement reactor FR-BEL or FR-BAL.



■ Wiring distance

- If the wiring is long, the charging current caused by the suspended capacity of the wiring may cause the fast response current limit function to activate. Make sure that the maximum wiring length is less than the values in the table below.

Inverter capacity		0.1K	0.2K	0.4K	0.75K	1.5K	2.2K	3.7K
During non-low noise operation	100V class	100m	100m	100m	100m	100m	100m	100m
	200V class	100m	100m	100m	100m	100m	100m	100m
During low-noise operation	100V class	30m	30m	100m	100m	100m	100m	100m
	200V class	30m	30m	100m	100m	100m	100m	100m

- When automatic torque boost is selected, make sure that the length of the wiring between the inverter and motor is 30m or less.

■ Grounding

- When the inverter is run with low-noise, the leakage current will increase because of the high-speed switching compared to the non-low noise operation. Always ground the inverter and motor. Always use the inverter's grounding terminal to ground the inverter.
- For 400V class, make save to ground the supply nevtal.

■ Noise

When carrying out low-noise operation with the carrier frequency increased, the magnetic noise will tend to increase. Refer to the following countermeasures, and act accordingly. Depending on the installation state, the effect of noise may be apparent even during non-low noise operation (default state).

The radio noise filter FR-BIF is effective against static noise heard in AM radio broadcasts.

■ Leakage current

Electrostatic capacitance occurs between the inverter's input/output wiring, other wiring, grounding and motor. The leakage current can flow through these and cause the earth leakage breaker, leakage relay and external thermal to operate unnecessarily. Take measures by lowering the Pr. 72 carrier frequency, using harmonics and surge compatible parts for the earth leakage breaker, and using an electronic thermal O/L relay built into the inverter.



Safety Warning

To ensure proper use of the products listed in this catalog,
please be sure to read the instruction manual prior to use.

ACP&D Limited
Units 6 & 9A,
Charlestown Industrial Estate,
Robinson Street,
Ashton-under-Lyne,
Lancashire, OL6 8NS.

Tel: +44 (0)161 343 1884
Fax: +44 (0)161 339 0650
e-mail: sales@acpd.co.uk
Websites: www.acpd.com &
www.acpd.co.uk



 **mitsubishi electric corporation**